

# SILVER STAR VIB-RATING EGG

## User manual



### CONTROL

- 1) Insert two AA batteries (not included) into the remote control.
- 2) There is a wheel on the side of the remote control that is used to turn on and off, as well as to continuously adjust the vibration.

### MAINTENANCE

After each use, rinse the penis with lukewarm water and soapy detergent. You can also use an **erotic cleaner**, which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The penis **is not waterproof or water resistant!**

### LUBRICATION

Due to the material of the vibrator, you can use **lubricants of any base**.

### DRIVE AND CHARGING

The penis is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

Deployable penis with remote control, including clamping belt.